

Installation Guide


TiVo Wi-Fi Adapter



What's included



TiVo USB Wi-Fi 5 Adapter



USB extension cable



Velcro

Step 1: Set up and plug into your TiVo media player.

A. Attach the included USB extension cable to the USB adapter and plug the extension cable into the USB slot on your TiVo media player.



Step 2: Connect to a wireless 5GHz network.

A. Place USB adapter on top of the TiVo media player. Use the velcro to secure the adapter.

Tip: For best reception, position the adapter as close as possible to your Wi-Fi router.

B. The TiVo Wi-Fi 5 USB Adapter operates on 5 GHz networks. When prompted to choose a wireless network during setup, select the 5 GHz network.



myaccess.ca | 1-866-363-2225

25.007011

